


### A. Features


- ➤ 13 Digits LCD Display, Display Hour, Minute, Second, Month, Day, Year and Week
- ➤ Automatic Calendar(2000~2099)
- Dual Time
- ➤ 12 / 24H format selectable, Auto Calendar
- Daily Alarm ,Chime hourly and SNZ
- ➤ 1/100 second to 23 hour 59.99 second Chronograph with split functions,12 groups of LAP segment timing
- Countdown function
- ➤ EL backlight
- > Touch-tone

### **B**. Operational Manual



- 1. At any mode, press A key EL backlight for 3s.
- 2. Press B to change the display mode
- 3. In real time mode press D key to switch 12 hours or 24 hours display.
- 4. Real Time and date
- > Time Setting
  - a). Press and hold C key for 2s to time setting mode and "Second" flashing, Press B key to select item as following sequence :


2016-12-13 Model: CRH123 Page: 1 / 2 Edition : A



- b). Press D key while the seconds are in the range of 30 to 59, resetting them to 00 and adding 1 to the minutes. While the seconds are in the range of 00 to 29, the minutes won't be changed.
- c). Press D key to adjust the value increment, hold down D key to quickly adjust.
- d)Press C key to return to Real Time Mode.
- e)In setting mode. 1 minute No key operation automatically exit setting, return to real time display mode.

#### 5. Dual Time Mode

In the real time mode, Press B key 3 times to enter Dual Time Mode, Press and hold C key for 2s to select "Hour" setting, Press B key to select "Minute" setting,




- Press D key to adjust the value increment, hold down D key to quickly adjust.
- > Press C key again to finish setting ,and return to Dual Time displaying mode .
- In setting mode. 1 minute No key operation automatically exit setting, return to Dual Time displaying mode.
- > The second of Dual Time is the same as real time

#### 6. Daily Alarm


- > Turn On / Off Alarm, Chime and Snooze
  - a) In Alarm mode, Press D and then Press C key to turn on/off Alarm ( ),
  - b) In Alarm Mode, press C to turn on/off hourly chime( 4) and snooze("SNZ"),

2016-12-13 Model: CRH123 Page: 2 / 2 Edition : A



#### **Alarm Mode:**

➤ In alarm mode, press and hold C key for 2 seconds to enter the alarm time setting state, then press B key to select the setting items as follows:



- ➤ Press D key to adjust the value increment, hold down D key to quickly adjust.
- > Press C key to return to Alarm Mode.
- ➤ In setting mode. No any key operation then will back to alarm display mode automatically after 1 minute.

### Remarks:

- ➤ When you need a daily alarm, do not enter a number at the bottom of the screen. Please set it to "---".
- ➤ When you need a specify month alarm, you need to enter the number "12- -" at the bottom of the screen.

2016-12-13 Model: CRH123 Page: 3 / 2 Edition : A

- ➤ When you need a specify day alarm, you need to enter the number "- - 30" on the bottom of the screen.
- ➤ When you need a specify date alarm, you need to enter the number, such as "12-30" at the bottom of the screen.
- When Alarm is ON, the BB-BB ring sounds for 10 seconds, the alarm when the screen symbol " " flashing, press any key to stop.

### **Snooze function:**


- ➤ In the Snooze function, The symbol "SNZ" is still flashing on the screen when the alarm stopped , snooze rings every 5minutes, total ring 6 times.
- When the snooze is ringing, press any key is to stop all the after snooze function.

### 7. Chronograph mode

- The measurement range of chronograph is 23 hours 59 minutes 59.99 seconds, when reach the maximum, the chronograph re-count from "0"
- ➤ Chronograph LAP segment timing can remember 12 groups.

### When running the Chronograph:

- Press D key to Start/Stop running; When stop, press C key to zero.
- When running, press C key to split counting. Press C key again to next LAP split counting.
- In the split counting, press D key to stop counting, Press C key to view the memory mode, press C key again to continue to view the next memory.
- When exit split count, hold on C key for 2 seconds to zero.
- When running, press B key to return to Real Time mode, and it runs at back.




LAP3 Stop LAP 2 Review LAP1

#### 8. Countdown mode


The display range of the timer is 1 minute to 23hour 59minute.

### In the countdown mode

Press and hold C key for 2s to time setting mode and "Seconds" flashes. Press B key to select "Hour", then Press B key "Minute" setting.



- Press D key to adjust the value increment, hold down D key to quickly adjust.
- Press C key to confirm, press B key return to the real time mode.
- In setting mode. No any key operation then will back to countdown mode automatically after 1 minute.
- Press D key to Start/Stop counting. Press C key for 2s to starting value when stop counting. Press C key for 2s again back to the setting mode.



When the countdown stop to zero, the BB-BB - ring sounds for 15 seconds, press any key to stop the ring, when the ring stop, the countdown time will automatically return to the initial setting time.

### C. Specifications

Module Size : Ф37.2mm

Module Thickness (include buzzer): 9 2mm

Operational Temperature Range : -10°C∼+60°C

Operational Voltage : 3.0V

Accuracy  $\pm 45 \text{sec/month}$ 

**Battery Code** : CR2025(capacitance: 170m Ah)

static average current : ≤1.5u A (static maximum current: 3.5 u A) Alarm average current  $\leq 2m A$ (Alarm maximum current : 5.0m A)

> ≤8m A (EL lighten maximum current : 10m A)

Model: CRH123 ≥36 month (Japan Lithium)

- EL lighten average current Battery life (85%)

(Battery life calculate according to EL lighten four times each day for 3 seconds each time, alarm for 60 seconds each day)

2016-12-13 Model: CRH123 Page: 6 / 2 Edition : A